

6555 Powerline Road - Suite 405 • Fort Lauderdale, Florida 33309 • Ph.: 754.900.7816

Toll Free: 844-8533458 • www.equilamna.com • sales@equilamna.com - Rev. 01

<u>equilam)n.a.</u>)

1 – Indirect Heating throug	zh water iacket accordi	ng to ASTM B-117 to		2
ensure that no metallic he				
2 - Lid engineered with sm	-		<u>F</u>	R J
B-117, for prevention o		-		
3 - Unibody construction in		-		4
one cabinet.		,	1	
4- Central Atomization Tov	ver engineered to AST	M B 117 standards		
	-			
ensuring fog uniformity and homogenous results		•	¢	Castors
Data Acquisition Software - option: - By PC (RS 232, USB or RS 485)		20		
UL508A Compliance		Included		
Lid security system		Included		
Visual and audible security system		Included		
Internal Dimensions W x D x H (mm)	820 x 650 x 780	1,190 x 820 x 830	1,400 x 850 x 850	2,050 x 1,080 x 1,000
External Dimensions W x D x H (mm)	1,460 x 1,100 x 1,440	1,870 x 1,125 x 1,650	2,420 x 1,150 x 1,700	3,400 x 1,600 x 1,800
Approx. Crated Dimensions W x D x H (mm)	1,600 x 1,150 x 1,700	2,050 x 1,300 x 1,900	2,600 x 1,300 x 1,850	3,550 x 1,700 x 2,110
Approximate net weight	205 kg	210 kg	364 kg	550 kg
Approximate Shipping Weight - Crated	258 kg	280 kg	417 kg	850 kg
Approximate test volume in liters (L)	600	1,000	1,300	3,000
Recommended Lab conditions	Temperature: 63 °F (17°C) - 82°F (28°C),			
Electrical Supply	Relative humidity: Maximum 85% (without condensation) 208 - 230 V Ø1 50/60Hz			
FLA (230V)	25A 35A			
Test water requirement	ASTM D 1193 Type IV			

6555 Powerline Road - Suite 405 • Fort Lauderdale, Florida 33309 • Ph.: 754.900.7816

Toll Free: 844-8533458 • www.equilamna.com • sales@equilamna.com

<u>equilam</u>n.a.)

DI water pressure	7 to 28 psi (0.5 to 2.0 kgf/cm²)			
DI water input Ø	1/2"			
Constant Pressure	56 psi +/- 0.7 psi (4 kgf/cm²)			
Water Supply	Chamber cleaning			
Corrosive Agent	Per Standard			
Lab exhaust	Fume Hood and motor – if necessary			
Drain	½" PVC tubing or PVC drain 4" at least			
Chamber exhaust	PVC 2" pipe without siphon	4"		
Measurement items: pH, Conductivity NaCl concentration	In accordance with ASTM B 117, JIS Z 2374, ISO 9227			
Service Area	minimum of 19.6" (50 cm) for an easier cleaning, assembling and maintenance			
1 (One) Year Parts Warranty against manufacturing defects from date of delivery at customer's site. This assumes equipment is used under normal operating conditions in accordance to the instruction manual. This warranty does not apply to glassware (lamps). In case of non-warranty issues during warranty period, actual expenses shall apply.				
Note 1: All our equipment is delivered with Installation, Maintenance and User Manual. We believe this material is enough for the correct use of the equipment. We are available for further questions and clarifications. Additionally, if desired, we can provide the technicians to assemble the equipment and conduct staff training at the client's site. (Cost available upon request).				
Note 2: Appearance and specifications of equipment are subject to change without prior notice.				
Note 3: We highly recommend that you don't use the same chamber for different solutions, e.g. don't use a Salt Spray				

chamber for CASS; Kesternich (SO2) test or CASS chamber for humidity test due the chemical contamination that may distort the results. See item 4.6 of Standard ISO 9227.



Optional Accessories

(1) reach 15° or 20° indiration in	
 (1) rack - 15° or 20° inclination in accordance with ASTM B117 and ISO 9227. 	
 Special rack for customer supplied test sample. 	Factory Consult
• (2) Fog collectors.	
 Pressure regulator with water, oil filter and pressure gauge. 	
• Fiberglass Fume Hood (hood only).	CELES CELES
 Fiberglass axial fan assembly capacity: 1940 cfm. Net weight: 88 lbs.(40 kg). 	
 DI Water assembly includes: activated carbon water filter, DI column, LED water quality indicator. 	
• Spare DI water column.	
• Spare activated carbon water filter.	
 Density meter to measure concentration of saline solution in accordance to ASTM B 117. 	
• 6 x 2.20 = 13.2 lbs. (6 x 1 = 6Kg) of NaCl.	200



 Test Panels – 2.9" x 5" (76mm x 127mm). In accordance with ASTM B 117 (100 Pieces). 	
• Test Panels – 2.7" x 5.9" (70mm x 150mm). In accordance with ISO 9227 (100 pieces).	
 Data Acquisition Software: By PC (RS 232 or USB) 	
• Grid type test brackets supports 120 kg with distributed load.	
• Cable port $\phi = 2" - EQOP 0034$	

Further optional requests shall be considered upon request.





